

Economic Feasibility Study on the Supercritical Fluid Extraction of Edible Oils

Michael Gifford, Elizabeth Biancani, William Kearsley, Walter Maluchnik, Stephanie Farrell, Mariano J. Savelski, and Robert P. Hesketh

Supercritical carbon dioxide extraction is currently used in several food and pharmaceutical manufacturing applications. Its "greener" nature makes it a desirable option when compared with traditional organic solvent extractions. The purpose of this work is to compare the cost of using supercritical CO_2 to commercially extract peanut oil with that of the traditional hexane extraction process. Solubility values of peanut oil in supercritical CO_2 were also obtained under different conditions of temperature and pressure.



Supercritical Fluids

- Critical Temperature and Pressure
- Properties
 - Density of a liquid
 - Viscosity of a gas
 - Low surface tension
 - Adjustable density



Supercritical Fluids in Industry

Reactions

Chemical

Engineering

- SC Water Oxidation

Rowan University

- Catalysis
- Pharmaceuticals
 - Particle Formulation
 - Drug Delivery
- Extraction
 - Petroleum
 - Coffee Decaffeination
 - Essential Oils



http://www.expsep.co.uk/

Carbon Dioxide Extraction

• Why CO₂?

emical

Engineering

- "Greener" alternative to organic solvents
 - Non-toxic

Rowan University

- Nonflammable
- Relatively Inert
- No detectable residue
- Nonpolar solvent
- Low critical conditions
 - Tc = 31.1°C
 - Pc = 72.8 atm
- Low cost



Rowan Environmental Engineering Department

Experimental Apparatus

- Supercritical Fluid Technologies SFT-150
 - LED Temperature display/controller
 - Precision: ± 0.5°C

Rowan University

COLLEGE OF ENGINEERING

emical

Engineering

- Max Vessel Temperature: 300°C
- Max Operating Pressure: 680atm
- Max Flowrate: 250g/min CO₂
- Rupture disc safeguard
- External Collection Vessel
- Hand-tight vessel seals





Materials

Peanuts

- Extra large, raw, unsalted
- Supplied by Natural Health, Clementon, NJ

Carbon Dioxide

- Bone dry liquid with educator tube
- 99.8% purity
- Supplied by Messer Gas Technologies & Service Group



Procedure

- Setup
 - Sample chopped in food processor for 1min ± 0.1s
 - Loaded and packed into vessel
 - Glass wool used to prevent entrainment
 - Temperature and pressure set
 - CO₂ flow initiated
- Sampling
 - Sample weighed at volume increments
 - Gas volume recorded



Solubility Determination

bemical

Engineering

Rowan University



Peanut Oil Solubility

Chemical

Engineering

Rowan University





Hexane

- Major Process Costs
 - Materials (Peanuts, Hexane)
 - Distillation





Supercritical

- Major Process Costs
 - Materials (CO₂, Peanuts)
 - Compression





Results

- CO₂
 - 0.07\$/lb
 - Max Solubility
 - 38 mg/g
 - CO₂ Flow
 - 87 million lb/yr
 - Energy input
 - 1.8 GWh/yr
 - Operating Cost
 - 6.2 million \$/yr

- Hexane
 - 0.07\$/lb
 - Max Solubility
 - 80mg/g
 - Hexane Flow
 - 38 million lb/yr
 - Energy input
 - 4.6 GWh/yr
 - Operating Cost
 - 14 million \$/yr

Cost Comparison Hexane vs. CO₂

Conditions

emical

Engineering

- Peanut feed = 10 million lb/yr
- Yeild = 30% (3 million lb/yr oil)
- Supercritical extraction conditions
 - P = 550bar

Rowan University

- T = 55°C
- For separation, P = 270bar
- Use mass and energy balances with solubility data to determine the more energy efficient process



Conclusion

- SCFE Advantageous for Oil Extraction
 - Economical, uses half the energy of distillation
 - More environmentally friendly than hexane
 - Improved plant safety
 - One-step process



Future Plans

- Further Economic Studies
 - More detailed, broader analysis
 - Compare product qualities
- Improve Solubility Data
- Explore Other Oilseeds
- Develop Undergraduate Experiment